



Safety Smartwatch  
**safeRANG**

Always and everywhere,  
feel protected with safeRANG



## EMERGENCY SITUATIONS & SAFETY



Location and voice recordings are sent 3 times to guarantee delivery.



### SOSsiren

In an emergency situation, just grasp safeRANG to activate a loud siren to call for help whilst simultaneously alerting your contacts with your location. Ideal to counter physical violence, assault or attempted robbery.

**01** Just grasp safeRANG for 2 seconds to activate the siren and deter the opponent. Even if your phone is taken by the attacker, the alert functions will activate at least one time.



### SOSsecret

Alternatively in an emergency situation, secretly call for assistance without letting the opponent know.

**02** Simply hold safeRANG for 5 seconds to call and message your emergency contacts without sounding the siren. If you accidentally activate the siren, press anywhere on safeRANG to deactivate. Ideal for threatening situations which you don't wish to overtly escalate.



### SOSsiren

In an accident, simply hold safeRANG to instantly connect with your emergency contacts.

**03** Send detailed information such as your location and voice recordings just by grasping safeRANG. Ideal for letting people know your situation and needs if you are alone or isolated.

safeRANG – the world's easiest-to-use safety smartwatch. All functions are activated by just one touch, giving you complete peace of mind on your wrist.

## SECRET SAFETY & PREVENTION



### SEND RECORDING

If faced with abusive or threatening verbal behavior, instantly and secretly record the situation and send it automatically to a pre-defined contact. Ideal for capturing your co-workers abuse or even your university lecture.

**04** Simply press 9 o'clock on safeRANG for 2 seconds. The recording file can provide evidence at a later stage.



### SEND LOCATION

Let friends or emergency contacts know your exact location just by grasping safeRANG.

Ideal for confirming you've arrived safely or letting friends know exactly where to meet.

**06** Just grasp safeRANG for 1 second and feel safe in the knowledge that your loved ones know exactly where you are.

## HANDY LIFESTYLE FEATURES



Recording



Finding Phone



Selfie




Hand Grip


# THE SAFETY SMARTWATCH, safeRANG

A simple grasp of safeRANG activates an emergency siren and sends your precise location, a recording of the event, and a picture of the surroundings to your pre-chosen emergency contacts. With its unique, fast and secret operation, safeRANG does not need you to look at a screen or find a tiny button during an emergency. It's simple, intuitive, and without false-alarm.

---

SOSsiren	: Siren, send Location, send Recording, send Picture	2 seconds	
SOSsecret	: Call, send Location, send Recording	5 seconds	
I'm Here	: Send Location	1 second	

---

Record	12 o'clock	2 seconds	
Find Phone	6 o'clock	2 seconds	

---

Dimensions	Diameter 31mm / Thickness: 9.4mm		
Weight	2g		
Bluetooth	Bluetooth 2.0(BLE)		
OS	Android 4.3 and above / iOS7.0 and above		
Waterproof	Splash Resistant		
Battery	CR2032		
Battery Life	Circa 3 months depending on usage		
Company	DNX		
Website	<a href="http://www.saferang.com">www.saferang.com</a>		

---

※ due to permission restrictions within iOS some functions are not available (SOS calls, record, find phone)